


LADIES ZIPPER PANT SIZE CHART



DETAIL	GXS	GS	GM	GL	GXL	WS	WM	WL	WXL	W2XL
A=LENGTH	34	35	36	37	38	39	40	41	42	43
B=WAIST	10.5	11	12.5	12	12.5	13	13.5	14	14.5	15
C=INSEAM	22	23	24	25	26	27	28	29	30	31
D=LEG OPENING	5.5	5.75	5.75	6	6.25	6.25	6.5	6.5	6.75	7